

CLEANING INSTRUCTIONS FOR SOFFIT AND SIDING

Good Cleaning Practices

General surface cleaning maintenance is required to prevent dirt and other particles from accumulating. These build-ups and deposits take away from the original beauty of Alumaboard® Products. Alumaboard® warranties require the purchaser to implement a regular cleaning schedule in order to preserve the appearance of the product.

- Clean the finish surface with water and a soft brush or sponge until it is free of debris. Avoid excessive rubbing as this will alter the finish.
- If required the finish surface may be also cleaned with a mild detergent (pH 6-7) or a cleaning agent diluted to 1:50 parts of water.
- Certain cleaning agents may damage the paint finish. If you are unsure about possibly damaging the surface, do a spot test on an area that is not easily visible. If the solution causes any damage or changes the look of the paint finish or gloss, immediately discontinue use. Always observe the recommended safety precautions including appropriate skin and eye protection to prevent irritations or burns.
- After each cleaning occurs, the surface must thoroughly be rinsed with water to remove any cleaner residue.
- To minimize the appearance of water spots and streaking, the surface should be wiped dry with a clean, soft, dry cloth.

Bad Cleaning Practices

- Do NOT use a pressure washer.
- Do NOT use steel wool, abrasive pads, or dirty rags.
- Do NOT use acetone, paint thinner, or any type of stripper/remover.
- Do NOT use highly acidic or alkaline solutions of any kind

